


User Instructions – Mobile AV A18 108/209

Data Projector Remote



Amplifier Switch



To watch VHS Video

- Turn **Data Projector** on with remote control
- With remote control, use **INPUT** button to select **Video**
- Turn on **VHS Video Player**
- Insert video and press play
- Alternatively, watch on TV using Line-A button on TV*

To turn volume up and down

- Check **Amplifier** is on
- Select **AUX-2** from **INPUT SELECTOR** on **Amplifier**
- Adjust the Amplifier's volume

To watch DVD

- Turn **Data Projector** on with remote control
- With remote control, use **INPUT** button to select **S-Video**
- Turn on **DVD Player**
- Insert DVD and press play
- Use the DVD remote control to navigate DVD menus
- Alternatively, watch on TV using Line-B button on TV*

To turn volume up and down

- Check **Amplifier** is on
- Select **DVD/AUX-1** from **INPUT SELECTOR** on **Amplifier**
- Adjust the Amplifier's volume

To watch Betamax Video

- Turn **Data Projector** on with remote control
- With remote control, use **INPUT** button to select **Video**
- Turn on **VHS Video Player** and change channel to **AV**
- Turn on **Betamax Video Player**
- Insert video and press play
- Alternatively, watch on TV using Line-A button on TV*

To turn volume up and down

- Check **Amplifier** is on
- Select **AUX-2** from **INPUT SELECTOR** on **Amplifier**
- Adjust the Amplifier's volume

To listen to Audio CD

- Turn on **Amplifier**
- Select **DVD/AUX-1** from **INPUT SELECTOR** on **Amplifier**
- Turn on **DVD Player**
- Insert Audio CD and press play
- Adjust the Amplifier's volume
- Use the DVD remote control to navigate CD

To watch Satellite TV

- Turn **Data Projector** on with remote control
- With remote control, use **INPUT** button to select **Video**
- Turn on **VHS Video Player** and select the channel
- Alternatively, watch on TV using Line-A button on TV*

To turn volume up and down

- Check **Amplifier** is on
- Select **AUX-2** from **INPUT SELECTOR** on **Amplifier**
- Adjust the Amplifier's volume

To listen to Audio Cassette

- Turn on **Amplifier**
- Select **Tape/MD** from **INPUT SELECTOR** on **Amplifier**
- Turn on **Cassette Tape Deck**
- Insert Audio cassette and press play
- Adjust the Amplifier's volume.

Notes

Please remember to press green I/O button twice using remote control to turn off projector on completion of class.

Room Support

Contact support using supplied intercom handset. The intercom is a direct line to staff in Room 210